

BoonDocker Filter Update Instructions

This kit provides an updated filter for the nitrous solenoid. There is a small blue filter located inside the Nitrous Manifold that should be removed.

Installation Instructions:

- 1. Remove the fitting that attaches the braided hose to the nitrous solenoid. This fitting is on the side marked "IN".
- 2. Thoroughly clean the threads. Any remaining debris will bypass the filter and go straight to the Nitrous Manifold!
- 3. Install the Nitrous Filter onto the nitrous solenoid. Use Teflon tape on the threads be sure not to get any tape on the inside of the threads, which will quickly clog the filter!





- 4. There is a small blue filter located on the Nitrous Manifold behind the brass compression fitting that holds the black poly line. Remove this fitting and remove the blue filter.
- 5. Thoroughly clean the threads. Any remaining debris will plug the small nitrous orifice holes and prevent the manifold from spraying! Reinstall the fitting with Teflon tape be sure not to get any tape on the inside of the threads!

